

BAZOOKAGOAL

SAFETY AND MAINTENANCE INSTRUCTIONS

1. Do not use your BazookaGoal in extreme weather conditions
2. Do not sit on your BazookaGoal when it is open
3. Fully extend always the telescoping site poles before you bend them down 90 degrees.
4. Never press the **PUSH** button before you have telescoped out the site poles. Pressing the button is the final step of the unfolding procedure
5. CHILDREN UNDER 12 YEARS ARE NOT ALLOWED TO FOLD AND UNFOLD THE BAZOOKAGOAL
6. Don't leave the BazookaGoal folded in the sun or beside a heating source or in storage rooms which has temperature above 30 degree. This can lead to deforming of the PVC tubes due to the internal pressure of the springs.



PARKLIFE INNOVATIONS LTD
Third Floor 111 Charterhouse Street
London, EC1M 6AW, UNITED KINGDOM
TEL: 0203 2125 07